




Ditec CUBIC6FM

IP1818

Manuale di installazione finecorsa magnetici per CUBIC6
Installation manual for magnetic limit switch for CUBIC6
Manuel d'installation de fin de course magnétique pour CUBIC6
Wartungshandbuch für magnetisch Endschalter für CUBIC6
Manual de instalación de fin de carrera magnético por CUBIC6
Manual de instalação de fim de curso magnético para CUBIC6





ENTRE//MATIC



Entrematic Group AB
Lodjursgatan 10
SE-261 44, Landskrona
Sweden
www.ditecentrematic.com

